



TEL + 44 (0) 116 260 1965

Angled Reed Spacer

Thickest part of Spacer goes to the top.

Your hardware includes

4 M6 40 for the Top holes

3 M6 45 for the Centre

4 M6 30 for the Bottom holes

11 Washers

1 Gasket

Leave everything as OEM and add the Spacer, apply some sealant to the gasket surfaces before re-assembly.

When fitting any spacer flat or angled this will move your carbs closer to your exhaust hose. Make sure the holes in the carb diaphragm covers are not being blocked by this hose. If they are pull up the exhaust hose and cable tie in place and/or you can turn your covers around so the holes are unobstructed and at the top. Single carbs are unaffected.