



Mini Steering system

This system is pre assembled, do not disassemble. Simply screw the boss into place on handlepole with the supplied 4 x M6 Stainless bolts, slide the steering onto the boss and tighten top M10 bolt. No shim is 28.6, with shim 22.2

DEM Handlepole Pre 2008 -the steering stop will need to be raised, a minimum height of 30mm to ensure it meets the stops on the steering.

DEM Handle Pole + 2008- The steering stop is cast into the pole, drill and tap the top of this and bolt on the supplied stop (if ordered)

DISCLAIMER

You the purchaser accept ALL responsibility for any conceivable damage caused whilst installing this product. Inexperienced persons may wish to peruse professional guidance from a qualified person before attempting installation of this product. These instructions have been prepared as guidelines and given in good faith for experienced users of the tools and materials needed for the installation of this product. The owners and manufactures of Air Time Products cannot be held accountable for any injury resulting from the use, misuse or misapplication of this product. For competition use only.

- Copyright © 2012-17 Queenford Leisure. ALL RIGHTS RESERVED