



ATP Performance Waterbox for the Kawasaki SXR

1. Remove engine, tank and Waterbox
2. Loosen the exhaust hose clip towards the rear of the hull
3. Remove coupler and spacer from water box
4. Place the ATP Waterbox in situ, here you will see minor trimming of the polystyrene may be required
5. Place the supplied 90 degree elbow onto the ATP Waterbox, if required chamfer this to sit level around the base of the aluminium exit tube.
6. Fit new supplied aluminium spacer to the elbow and connect to exhaust hose
7. Tight all hose clips and secure your new ATP Waterbox with your OEM straps- These will require a knot tying in them to now make them shorter.

Note: If using an aftermarket exhaust, use OEM coupler to Waterbox.



DISCLAIMER

You the purchaser accept ALL responsibility for any conceivable damage caused whilst installing this product. Inexperience persons may wish to peruse professional guidance from a qualified person before attempting installation of this product. These instructions have been prepared as guidelines for experienced users of the tools and materials needed for the installation of this product. The owners and manufactures of Air Time Products cannot be held accountable for any injury resulting from the use, misuse or misapplication of this product. For competition use only.

