

TRIGGER



Insert Ventilation Tube. Push FIRMLY and twist until you feel the tube fully seat.



Correctly assembled Trigger.



Apply downward pressure when hand tightening. Ensure correct thread alignment to avoid cross-threading. Do not over tighten.



Tilt container. Press trigger for flow. Release trigger to stop flow. Keep Trigger button upright while pouring.



Trigger is self-venting. Ensure all vents on container are closed.

Air Time Products



Patent #8,573,452



WWW.STROKERINDUSTRIES.COM

STROKER
INDUSTRIES